

MOVIMENTO PENDOLO CU-CU' "TIME CONTROL" PENDULUM CUCKOO MOVEMENT "TIME CONTROL"

ISTRUZIONI / OPERATING MANUAL

- A) Inserire tre batterie tipo "C" (non incluse) nello scompartimento (1): il rilevatore delle ore inizierà a funzionare.
- B) Appendere il pendolo in questo vano (2); piazzare i ganci negli anelli e fissare i finti pesi (pigne) sulle catene attaccate sul fondo della cassa.
- C) Premere delicatamente un lato del pendolo per iniziare il movimento di oscillazione.
- D) Spostare manualmente le lancette dei minuti sull'ora esatta.
- E) Premere il pulsante "reset" (4): le ore del cu-cù si posizioneranno automaticamente sulle 6:00 a.m.
- F) Aggiustare le ore del cu-cù premendo il pulsante (3) fino al raggiungimento dell'ora esatta. (N.B.: dopo aver resettato le ore del cu-cù sulle 6:00 a.m.. Ora se si preme due volte, le ore del cu-cù si sincronizzeranno sulle 8:00 a.m.; premendo sette volte, il cu-cù andrà sulle 1:00 p.m.)
- G) Girare il bottone (5) per regolare il volume (alto-basso) della suoneria.
- H) Cambiate le batterie nel caso in cui la suoneria del cu-cù sia inusuale ed il cu-cù non esca.
- I) Raccomandiamo di cambiare le batterie due volte all'anno per ottimizzarne il funzionamento.
- A) Insert three "C" batteries (not included) into compartment (1), then the timekeeper will begin.
- B) Hanging the pendulum in this holder (2), place chain hooks on the weight rings and hang the carved faux weights on chains attached to the bottom of case.
- C) Gently push pendulum to one side to start swinging motion.
- D) Move the minute hands to the correct time by hand.
- E) Push the reset button (4), cuckoo hour will be automatically corrected at 6:00 a.m.
- F) Adjust the cuckoo hour by pushing the button (3) until matches the correct time. (e.g. After reset the cuckoo hour remains 6:00 a.m.. Now if you push twice, the cuckoo hour would be 8:00 a.m.; push seven times, the cuckoo hour would be 1:00 p.m..)
- G) Switch the volume control (5) (high-low) to meet your need.
- H) Please change new battery in time in case of abnormal cuckoo sound and cuckoo's not coming out when alarms.
- I) We recommend that batteries be changed twice a year at least for optimum performance and enjoyment.

